




"OFF" MINIMUM CHARGE POSITION



"DIM" INTERMEDIATE CHARGE POSITION



"HIGH" FULL OUTPUT CONDITION



"EMG" THE EMERGENCY START

SHOWING THE EQUIVALENT CIRCUITS IN ALL THE SWITCHING POSITIONS